

# WYSIWASH SANITIZER-V INSTRUCTIONS

## WYSIWASH SANITIZER-V PARTS



### A. ADJUSTABLE NOZZLE

Changes the stream emitted from a gentle mist to a targeted stream.

**NOTE:** The Adjustable Nozzle attaches to the long end of the Hydro Body.

### B. HYDRO SEAL

Prevents leaking by securing the Caplet Container to the Hydro Body.

### C. CAPLET CONTAINER

Holds the Wysiwash Jacketed Caplets.

### D. HYDRO BODY

Mixing chamber that creates and measures the Wysiwash solution.

### E. FLOW CONTROL VALVE

Twist to turn ON/OFF the Sanitizer-V

**NOTE:** The Flow Control Valve attaches to the short end of the Hydro Body.

### F. FEMALE QUICK-CONNECTOR

Threads onto a standard garden hose, then attaches to the Sanitizer-V by pulling the neck back.

### WYSIWASH JACKETED CAPLETS:

The Wysiwash jacketed caplets are condensed calcium hypochlorite—a proven disinfectant/sanitizer

**NOTE:** Do **NOT** remove the plastic jacket from the caplet. If the plastic jacket has been removed or damaged, dispose of the caplet.

## HOW TO ATTACH THE WYSIWASH SANITIZER-V TO YOUR HOSE

1. Unscrew the Caplet Container from the Hydro Body (Part B).

2. Place caplet inside the Caplet Container (Part C). **Do not remove the plastic jacket.**

**Note:** We recommend you wear gloves when handling the Jacketed Caplets. While the Wysiwash solution does not irritate skin, in its solid or concentrated form (such as while priming and draining) it can irritate eyes and skin.

3. Secure the Hydro Body (Part D) of the Sanitizer-V to the Caplet Container. Tighten until snug, but do not over-tighten.

4. Thread the Female Quick Connector (F) onto your garden hose.

5. There is a “neck” on the front end of the Female Quick Connector that will slide back toward the hose end. Pull the neck back and insert the Sanitizer-V (Part E) into the Female Quick Connector. Then release the neck. After, press the two parts gently together to make sure the two parts are securely connected.

## SANITIZING WITH WYSIWASH

1. Turn on water to the hose.

2. To turn on the unit, twist the Flow Control Valve (Part E).

3. **PRIME:** Spray into a drain or bucket to prime the system. This ensures that the solution is at an effective concentration and any concentrate is flushed out.

(Prime 1-2 minutes for new caplets & 30-40 seconds for a used caplet.)

4. Allow Wysiwash to set for 2 minutes.

5. **OPTIONAL RINSING:** For uncoated metal or high gloss surfaces, we recommend rinsing.

6. Either squeegee, or allow the area to completely air dry.

## DRAINING THE WYSIWASH SANITIZER-V

1. Make sure the Flow Control Valve is OFF.

2. Disconnect the Sanitizer-V from the Female Quick Connector by sliding the “neck” of the female toward the hose side again to release.

3. In a bucket, drain, or sink, turn the Sanitizer-V upside down and point the valve downward.

4. Turn the Flow Control Valve on to allow the solution to drain. The bottom of the Caplet Container, should be pointed upwards at a slight angle. This allows water to drain from the bottom of the Caplet Container.

5. Store the Sanitizer-V in this position to maximize the life of your caplets.

**Draining is key to keeping your Wysiwash unit in good condition.**

**Drain Wysiwash any time you will go more than 15 minutes between uses.**

## SCAN THIS TO WATCH VIDEO INSTRUCTIONS

